

# Flex - Net

To achieve the maximum efficiency from Machine and Hand rolls the following is recommended.

## HAND ROLLS

1. Apply either with applicator or cups.
2. To start: - tie knot in netting and fix into groove in pallet base  
or  
- tie knot and tuck into gap between goods.



**Do not tie onto the pallet.**

3. Take netting to the top of the load and allow overlap of approx 15cm. Make 2 revolutions at top and come down load allowing overlap of approx 10cm. This can vary according to make up of load either cartons, bags or rolls.
4. At base of load make 2 revolutions including pallet, and end at point of "tie on". Cut and tie to lead or to itself.

**NOTE:**                    ***With bags or rolls, the netting will fit into the contours.***



**To achieve the best results the tension should be tight**

## MACHINE ROLLS

Adjust the tension of the machine to allow for the stretch. The appearance of the net as it covers the load can be a guide to the required tension.

To obtain the maximum efficiency it is recommended that care be taken to obtain the correct tension. This particularly applies where rigid type netting has been used.

2. To start: - tie on as above for Hand rolls.
3. Apply the netting as with Hand Rolls.
4. Finish off as for Hand Rolls.

## ***The Pallet Net with REFLEX ACTION***